

CONTRAINDICATIONS STRESS FREE MASSAGER

1. The following conditions should consult doctor before use:

- people suffer from heart disease
- people suffer from infectious disease
- people suffer from malignant tumor
- people has open cut on the skin
- women in pregnancy, menstruation and perpetual fever
- people with excessive sunburn
- people with sensitive skin or angiectasis or have been admitted to hospital.

2. Do not disassemble the device by yourself. Seek help from the authorized service center when necessary.

3. Do not use or place the device in a hot or humid environment to prevent functional defect or damage.

4. Do not charge the device under wet area to prevent the short-circuits.

5. Do not allow children or people with physical limitations to use the device without supervision.

6. This device is not water-proof. Do not leave it under water or inside corrosive environment.

7. Stop using the device immediately when any abnormalities from the device occurred.

8. Do not drop or hit the device to avoid any damage.

9. Essential oils may be applied during using the devlce to prevent skin from getting too dry.